

LIVOO
Feel good moments
Instruction manual

Half-barrel charcoal barbecue



Reference: DOC229
Version: 1.4
Language: English

Instruction manual

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

General Safety Instructions

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THE APPLIANCE AND SAVE IT FOR ANY FURTHER NEED.

Incorrect operation or usage is likely to cause damage to the appliance and injure the user. Make sure that you follow all safety instructions. Only use this appliance for the purpose for which it has been designed; we decline all responsibility in the event of damage due to incorrect use or bad handling.

1. The safety instructions do not by themselves eliminate any danger completely and proper accident prevention measures must always be used.
2. Never leave the appliance unsupervised when in use.
3. Only use the appliance for domestic purposes and in the way indicated in the instructions.
4. **The barbecue must be installed on a stable horizontal support before use.**
5. **The barbecue must be heated and the fire kept incandescent for at least 30 minutes before the first cooking.**
6. Use only charcoal in the fire bowl.
7. Do not fill the fire bowl above the level of the cooking grid.
8. The max. charcoal used shall be 1 kg.
9. **Do not cook before the fuel has a coating of ash.**

Instruction manual

10. It is absolutely necessary to keep this appliance clean at all times as it comes into direct contact with food.
11. Let cool and keep out the accessories before cleaning them.
12. Keep this manual with the appliance. If the appliance is to be used by a third party, this instruction manual must be supplied with it.
13. Regarding the instructions for cleaning with food, thanks to refer to the below paragraph of the manual surfaces in contact.

DANGERS

- **Warning: The temperature of the barbecue will become very high. Do not move the barbecue when operating.**
- **Warning ! Do not use indoors.** This barbecue is designed to be used only outdoors. Inside, toxic smoke build up and could cause serious injury or death.
- **WARNING! Do not use spirit or petrol for lighting or relighting! Use only firelighters complying to EN 1860-3!**
- **WARNING! Keep children and pets away**
- If you are using a liquid fire starter, remove any liquid that may have flowed through the bottom ventilation holes before lighting the charcoal.
- Do not use the barbecue within 50 meters of combustible materials. These include, but are not limited to wood or treated wooden decks, patios or verandas.
- Do not use the grill if all its parts are not in place. Check that the ash pan is properly secured to the feet under the barbecue tank.

Instruction manual

- Do not remove the ashes until the charcoal has fully burned and is not completely extinguished.
- Do not wear clothing with large, floating sleeves when lighting and using the barbecue.
- Do not use the grill during strong winds

Warning :



Caution hot surface!

DO NOT CLEAN OR TOUCH the metals part of this product when it is still hot



Do not use the barbecue in a confined and / or habitable space, for example houses, tents, caravans, campers, boats. Risk of death from carbon monoxide poisoning.

Instruction manual

This instruction manual is also available on our website www.livoo.fr

- Caution: do not, under any circumstances, cover the grill rack with aluminous foil, barbecue dishes or other items, as the resulting build-up of heat could cause irreparable damage to the grill.
- When grilling food with a high fat or moisture content, splashes are not always avoidable.
- Remember that the food with a high fat or moisture content may tend to ignite or to splash.
- No responsibility will be accepted if damage results from improper use, or if these instructions are not complied with.
- This Barbecue grill is not intended to be installed in or on recreational vehicles and/or boats
- Use heat-resistant barbecue mitts or gloves while cooking
- Use proper tools, with long, heat-resistant handles.
- Always put charcoal on top of the charcoal (lower) grate. Do not put charcoal directly in the bottom of the bowl.
- Do not store grill until ashes and charcoal are fully extinguished.
- Keep electrical wires and cords away from the hot surfaces of the grill and away from high traffic areas
- Do not use water to control flare-ups or to extinguish charcoal.
- Using abrasive cleaners on the cooking grates or the barbecue itself will damage the finish
- The barbecue should be thoroughly cleaned on a regular basis

BEFORE FIRST USE

- Clean with a soft damp cloth. Place your appliance on level and stable surface.
- Pre-heating the appliance 30 minutes without any food to remove the protective coating. A small smoke emission is normal; take care that the room is aerated well

PARTS LIST

Please check parts against the list below before assembling your barbecue grill. Take a few moments to familiarize with contents. Check that all holes are clear of paint before assembly.

1	Rear windshield	1pc	12	Handle	1pc
2	Right windshield	1pc	13	Axle	1pc
3	Left windshield	1pc	14	Charcoal grate	2pcs
4	Middle windshield	1pc	15	Grill handles	2pcs
5	Cooking grid	2pcs	A	M6X12mm bolts	24pcs
6	Bowl	1pc	B	M6x45mm bolts	4pcs
7	Long leg	1pc	C	M6 nut	24pcs
8	Short leg	1pc	D	Metal washer	4pcs
9	Cross bars	2pcs	E	Plastic washer	2pcs

Instruction manual

10	Condiment tray	1pc	F	M8 lock nuts	2pcs
11	Wheels	2pcs			

ASSEMBLY INSTRUCTION

BEFORE ASSEMBLY:

1. To assure fast and easy assembly. Follow the instructions below in their proper sequence.
2. Check all parts carefully and compare them to the parts listing.
3. Report any missing parts to the company from which you purchased the product.




WARNING

- While every effort has been made in the manufacture of your barbecue to remove any sharp edge, you should handle all components with care to avoid accidental injury.




- Tools required: either a crosshead or flat-bladed screwdriver and either an adjustable wrench or a pair of pliers.

ASSEMBLY STEPS



STEP 1

Turn the short leg (8) upside down, attach axle (13) to short leg (8) then fit wheels (11) using plastic washer (E) and lock nuts (F)




STEP 2

Fit condiment tray (10) with the two crossbars (9).


Screw long leg (7) and short leg (8) to the two cross bars (9) (which are holding the condiment tray) using bolts (B).

Instruction manual




STEP 3

Attach bowl (6) to long leg (7) and short leg (8) using bolts (A), and nuts (C). Attach handle (12) using metal washers (D) and bolts (A).



STEP 4

Place charcoal grate (14) into position in the bowl (6). Attach the left windshield (3) and right windshield (2) using bolts (A), and nuts (C).



STEP 5

Attach the middle windshield (4) using bolts (A) and nuts (C).

Attach the rear windshield (1) using bolts (A), and nuts (C).

Place cooking grills (5) into position.

Attach grill handles (15) to cooking grills (5).

Tighten all nuts and bolts

Warning: Ensure all fittings are fully tightened before use.

Now your barbecue is ready for use

Instruction manual

CLEANING AND STORAGE

1. Never use abrasive cleaners.
2. Do not use water on barbecue while hot as this will damage the finish
3. Never immerse in water.



LIVOO

BP 61071

67452 Mundolsheim-FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice