

Electric coffee maker



Reference : DOD163
Version : 1.4
Language : English

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

General Instructions

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE
PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Before use check that the voltage of your wall outlet corresponds to the rated voltage manner.
2. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard (*).
3. This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
4. Keep the appliance and its cord out of reach of children aged less than 8 years.
5. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way

and if they understand the hazards involved.

6. Children shall not play with the appliance.
7. Do not let cord hang over edge of table or counter or touch hot surface.
8. Do not touch hot surface. Use handles or knobs only.
9. Close supervision is necessary when your appliance is being used near children or infirm persons.
10. Do not place an appliance on or near a hot gas or on a heated oven.
11. Do not use outdoors (Household use only).
12. The appliance is not intended to be operated by means of external timer or separate remote-control system.
13. It is absolutely necessary to keep this appliance clean at all times as it comes into direct contact with food.
14. Regarding the instruction for cleaning surfaces in contact with food thanks to refer to the below paragraph "cleaning" in manual.
15. Appliance must not be immersed.
16. There is potential injury from misuse
17. The heating element surface is subject to residual heat after use.
18. Avoid spillage on the connector.
19. The appliance is only to be used with stand provided.
20. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments
 - farm houses

- by clients in hotels, motels and other residential type environments
- bed and breakfast type environments

(*) Competent qualified electrician: after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician

This instruction manual is available too on our website www.livoo.fr

SPECIAL SAFETY INSTRUCTIONS



WARNING :


Never touch the hot parts of the appliance (be careful, also the warm plate and the appliance is a hot part!). Only take the coffee maker by the handle.

TECHNICAL SPECIFICATIONS

Voltage: 220-240V 50-60Hz
Power: 800W

User manual

DESCRIPTION



USING INSTRUCTIONS

1. Before first use, clean the carafe, the reusable mesh filter and filter basket in warm soapy water, thoroughly rinse.
 2. Uncover the top cover and fill clean water to required level.
 3. Put adequate quantity of coffee powder in the filter cone (or paper filter) inside the filter holder.
 4. Place the carafe on the drip plate.
 5. Close the cover
 6. Switch on, the indicator lamp will light up and the appliance begin working
- Note : Caution: Do not open the reservoir lid during the brew cycle, as scalding may occur.
7. The appliance will brew until the water tank is emptied, then automatically switch into off mode within 40 minutes.
 8. Unplug from the socket.

WARNING: Before brewing another carafe of coffee, wait a few minutes to allow the Coffeemaker completely cool

GENERAL CARE AND CLEANING

1. Do not forget to remove the plug from the socket before cleaning the appliance.
2. Make sure that the appliance and especially the carafe are cool down before cleaning
3. Do not wash the carafe immediately after the use in order to avoid thermal shock
4. Clean the inside of the carafe with a soft brush in warm soapy water. Rinse with fresh water and dry it before next use.

Note: When washed in a dishwasher, the parts may appear to fade. Restore by polishing them with a soft, dry cloth.

5. Wipe outside with soft, moist cloth when appliance is cold down completely, never use metal polish.
6. Never immerse the cord, plug, or appliance itself in water.

DESCALING

1. The appliance has to be descaled regularly (minimum twice a year)
2. Operate two or three more brewing cycles with fresh, cold water to remove all descaler solution residues. Throw out the obtained hot water
3. The frequency depends on the water hardness. Generally, the descaling should be done every two months.

Operating :

- Place the carafe onto the Base.
- Mix three cups of vinegar and nine cups of cold water and fill the water tank up to the Max level with prepared solution.
- Switch on the appliance during one minute. Switch off then, and wait one half an hour.
- Press the Start Button. Allow all of the cleaning solution to drip into the carafe, throw out the cleaning solution and clean the carafe.
- Operate two more brewing cycles with fresh, cold water to remove all descaler solution residues.

LIVOO
Feel good moments
User manual



**Correct Disposal of this product
(Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems)**



The European Directive 2012/19/EU on Waste Facilities Electrical and Electronic (WEEE)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product or their local authority office, for details of where and how they can take this item for environmentally safe recycling.



LIVOO
BP 61071
67452 Mundolsheim-FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice