

Coffee grinder



Reference : DOD192
Version : 1.4
Language : English

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction

SAFETY INSTRUCTIONS

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user.

Assure that you use the appliance for the use for which it is designed, we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
2. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
3. Children shall not play with the appliance.
4. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments
 - farm houses
 - by clients in hotels, motels and other residential type environments

- bed and breakfast type environments
5. Check that your main voltage corresponds to that stated on the appliance. Multiple plug is misadvised.
 6. Do not use the appliance if your hands are damp or with naked foot.
 7. In case the appliance accidentally bad work, disconnect it immediately.
 8. Never unplug the appliance by pulling the cord. Make sure the cord cannot get caught in any way.
 9. Never leave the appliance unsupervised when in use.
 10. Never move the appliance when in use.
 11. Protect the appliance of the froze and humidity.
 12. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard (*)
 13. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning
 14. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
 15. Do not touch the blades and do not insert any object (knives, forks, spoons, etc.) into the bowl while the product is underway
 16. All appliances are submit to serious quality control. Some tries are doing at random, so that may have tracks of use.

User manual

17. Keep the appliance, the cord or main unit at a distance from hot objects, wet surface and sharp angle.
18. The appliance must be used with his supplied lid and main unit only.
19. Never immerse the base of your appliance, the cord or plug in water or any other liquid for any reason whatsoever. Never place it into the dishwasher.
20. The guarantee covers the manufacturing defects and the domestic use only. Any breakage or deterioration resulting from failure to respect the instruction of use does not enter within the framework of the guarantee.
21. Do not use wire brush or any abrasive items or liquids.
22. Do not fill over the maximum level, nor below the minimum level.
23. The appliance is not intended to be operated by means of external timer or separate remote control system.
24. Never disassemble the appliance yourself.
25. It is absolutely necessary to keep this appliance clean at all times as it comes into direct contact with food.
26. Regarding the instructions for cleaning surfaces in contact with food or oil, thanks to refer to the below paragraph "cleaning" in manual.
27. Regarding the instructions for the use of accessories, operation times and speed settings, thanks to refer to the below paragraphs.
28. Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.

29. There is potential injury from misuse.
30. Accessories, other than those supplied with the appliance, shall include instructions for their safety use.

(*) **Competent qualified electrician:** after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

This instruction manual is available too on our website www.livoo.fr

SPECIFICS MEASURES

Warning :

1. Never touch blades when the machine is connected.
2. Take away fingers, clothes, hair and utensils of the device hanging the mixture to decrease the risks of grave physical wounds or damage in the device.
3. Use the appliance no more than 10 seconds at the same time, a little let it rest before the next use to avoid any overheating.

TECHNICAL SPECIFICATIONS


Voltage: 220-240V~ 50-60Hz

Power: 200 W

KB: 1 minute and 10 seconds ON, 1 minute OFF, 3 cycles (maximum time of continuous functioning)

User manual

DESCRIPTION



1、Lid	6、Screw	11、Screw
2、Bowl	7、Body	12、Shaft and blade
3、Top body	8、Bottom panel	13、Screw
4、Switch fixed collar	9、Rubber feet	14、Wiring board
5、Motor	10、Power cord	15、Screw

USE

Before using the appliance for the first time clean all accessories in hot soapy water (except for the motor unit). Rinse and dry thoroughly every item. Make sure that all the packaging has been removed.

1. To start to use the coffee grinder, fix the bowl onto motor part by turning it in clockwise direction.
2. Fill the bowl with desired amount of coffee beans and set the transparent cover.
3. Press lid to active the coffee grinder and hold it down until the desired level of grinding is obtained.
4. To stop it, simply release the lid.
5. During grinding, if coffee powder starts collecting on the edge of the appliance where it is out of the reach of the blade, release the lid to stop the grinding process and shake the appliance gently so that coffee powder falls back inside.
6. After grinding your coffee, unplug the appliance, take off the transparent lid from the motor part and pour out the coffee grounds.

LIVOO
Feel good moments

User manual

Notes:

- For optimal flavors, it is recommended to grind coffee beans immediately before brewing.
- If grinding is excessive, use the sealing cover to cover it for better storage.
- The coffee grinding grade is influenced by the quantity of coffee beans added and the length of grinding
The longer the coffee beans are ground, the finer the coffee powder. Shooter grinding results in coarser coffee powder.

Grinding grade	Gram	Time
Coarse	70g	30s
Medium	50g	30s
Fine	30g	30s

CLEANING

1. Remove the plug from the mains socket. To protect against electrical shock, do not immerse cord, plug or unit in water or liquid.
2. Take off the cover from the blade cup and clean carefully with a soapy water.
3. Use a dry damp cloth to clean the motor part.
4. Never use wet cloth to clean the appliance.
5. All removable parts are dishwasher-safe on the top rack. Do not put parts on bottom shelf. Never immerse the grinder base unit in water or other liquid.

LIVOO
Feel good moments
User manual



**Correct disposal of the unit
(Electrical and Electronic Equipment)**

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream.

Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection.

Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice