

Stand electrical barbecue



Instruction manual

Language : English

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is also available on our website www.livoo.fr

General Safety Instructions

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THE APPLIANCE AND SAVE IT FOR ANY FURTHER NEED.

Incorrect operation or usage is likely to cause damage to the appliance and injure the user. Make sure that you follow all safety instructions. Only use this appliance for the purpose for which it has been designed; we decline all responsibility in the event of damage due to incorrect use or bad handling.

1. Check that your main voltage corresponds to that stated on the appliance.

Instruction manual

2. The safety instructions do not by themselves eliminate any danger completely and proper accident prevention measures must always be used.
3. Never leave the appliance unsupervised when in use.
4. Keep the appliance and its cord out of reach of children less than 8 years.
5. Children shall not play with the appliance.
6. Cleaning and use maintenance shall not be made by children unless they are older than 8 year and supervised.
7. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved

Instruction manual

8. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard (*).
9. Do not pass the cord over objects with sharp edges and keep it at a distance from, hot objects and bare flames. Always pull on the plug to disconnect it from the feed source
10. Make sure that the cord or the extension cable is not at risk of being pulled inadvertently nor of being topped over by anyone at the time of use
11. When you use an extension cable. make sure that it is adapted to the appliance essential consumption. Contrary to this, the extension cable and/ or the plug risks overheating.
12. Only use the appliance for domestic purposes and in the way indicated in the instructions.
13. Never immerse the base of your appliance in water or any other liquid for any reason

Instruction manual

whatsoever. Never place it into the dishwasher.

14. In case the appliance accidentally falls into water disconnect it immediately. Have it checked by an expert before re-using, if you do not do this you run the risk of electrocution.
15. Never try to open the casing yourself
16. Do not use the appliance if your hands are damp if the oil is wet, or if the appliance itself is damp
17. Do not touch the plug if your hands are damp or wet
18. Never use the appliance near hot surfaces.
19. Never use accessories that are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
20. Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any

Instruction manual

way. Do not wind the cord around the appliance and do not bend it.

21. Place the device on a flat, stable, heat-resistant surface.
22. Unplug the appliance when not in use.
23. It is absolutely necessary to keep this appliance clean at all times as it comes into direct contact with food.
24. Make sure the appliance is unplugged before inserting, removing or cleaning one of the accessories. It is absolutely necessary to remove the accessories before cleaning them.
25. Let cool and keep out the accessories before cleaning them
26. The appliance is not intended to be operated by means of external timer or separate remote control system.
27. Keep this manual with the appliance. If the appliance is to be used by a third party, this instruction manual must be supplied with it.
28. Never carry the appliance while still hot

Instruction manual


29. This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments
- farm houses
- by clients in hotels, motels and other residential type environments
- bed and breakfast type environments

30. Warning: Do not use charcoal with this appliance.

31. Always fill the grill pan with water before you switch on the appliance. The water helps to cool down the grill pan, reduces the buildup of smoke, and also facilitates cleaning.

32. Ensure that the water level is kept between the 'Min.' and 'Max.' markings at all times during use.



Instruction manual

← — —Min. water level

indicator

The water level indicator can be found inside the tank.

33.The appliance must not be used without water

34.Regarding the instructions for cleaning with food, thanks to refer to the below paragraph of the manual surfaces in contact .

35.The appliance I suitable for indoor use.

(*) Competent qualified electrician: after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

Instruction manual

Special measures

Warning :



Caution hot surface!

Surfaces are liable to get hot during use.

DO NOT OPERATE this product near water sources or flammable liquids.

DO NOT CLEAN OR TOUCH the metals part of this product when it is still hot

DO NOT USE SHARP OBJECTS

- Caution: do not, under any circumstances, cover the grill rack with aluminous foil, barbecue dishes or other items, as the resulting build-up of heat could cause irreparable damage to the grill.
- When grilling food with a high fat or moisture content, splashes are not always avoidable.
- Remember that the food with a high fat or moisture content may tend to ignite or to splash.
- Always ensure that the water level is kept above the 'Min.' mark so add water during the heating to keep right level and ensure that it does not come into contact with the heating element.
- Before the grill is used, always check that the heating element is correctly fitted in the grill pan and safely locked.
- Do not connect the grill to mains power until the grill pan has been filled with water. The tray salvage dealer of fat must be immersed and take care of not pour water on the heating element.
- Use only the supplied tray salvage dealer of fat .
- Ensure that the grill is not stored outdoors. Or in any other location where it might be subjected to extremes of temperature or high humidity.
- No responsibility will be accepted if damage results from improper use, or if these instructions are not complied with.

SPECIFICATIONS

Instruction manual

AC 220-240V 50-60Hz 2000W

DESCRIPTION & BARBECUE ASSEMBLY

Before using for the first time

Remove any packaging materials from the appliance.

Clean the tank, tray salvage dealer of fat and the grill pan

The tank must be filled with water up between MIN and MAX marking, never fill water on the heating element, it will damage it. Plug the appliance.


Let the grill heat up for a moment without any food, this will reduce the smell when first switching on a new grill (a slight smell and a little smoke may be emitted-ensure sufficient ventilation).

IMPORTANT TIPP

Do not forget to push the slot on thermostat to activate the heating process




Instruction manual




1. Tank

2. Metal hook




3. Handle + Base feet

Step 1: Insert the four base feet into the plastic handles according to the same direction as showing above.




Step 2: Install the plastic handles on the two sides of the tank by four screws.



4. Windshield

Step 3: Install the windshield onto the tank same way as above.


Instruction manual



5. Tray salvage dealer of fat


6. Nut

7. Metal pipe




Step 4: Insert the metal pipe into the tray salvage dealer of fat (No.5).

Step 5: Insert each side of the metal pipe (No.7) into the two small holes on the left & right sides of the tank (No.1) individually.



Step 6: Insert the small hole on the groove part of the tray (No.5) into the stretched screw, and then fix the screw by the nut (No.6).


Instruction manual



8. Heating Element

Step 7: Put the whole heating element (No.8) onto the base.



There is a small hole on the bottom side of the heating element. Make sure that the metal hook (No.2) is inserted inside the hole completely.



9. Big grid

10. Small grid


Instruction manual



Step 8: Put the big grid onto the BBQ.

Step 9: Put the small grid onto the windshield.

Stand Assembly:




A1.short leg A2.long leg A3.short metal shelf A4.long metal shelf A5.butterfly nut A6.M5 Screw

Step 1: Insert the short leg into the long leg, and ensure the hole on short leg can meet with hole on long leg to make the black screw inserting successfully.

Step 2: Put the short metal shelf and long metal shelf on the two sides of the pipe's hole (the direction for short line of both metal shelf shall be always onward), and insert the black screw into holes and finally fixed with the butterflyshaped nut, same as above diagram shows.

Instruction manual



A7. Rubber sockets A8. Lower grill

Step 3: Get all four legs fixed as a complete stand, same as the diagram above.

Step 4: Insert the 8pcs of rubber socket into the hole of stand separately.

Step 5: Put the lower grill onto the stand and put the table BBQ onto the stand.

Step 6: Now you are ready to use the Barbecue.

USE

1. The tank must be filled with water up between MIN and MAX marking, never fill water on the heating element, it will damage it. Plug the appliance.
2. Set the thermostat control knob on the temperature MAX and after 5-10 minutes, heating element is ready. The indicator light turns on and off during the heating, that's normal.
3. The water in the tank will evaporate during use. So you must to fill up water from time to time. Be careful not to pour water on the heating element.
4. When you grilling the food stuffs, you have to return them sometimes with adapted accessories and you can choose the temperature you want.
5. The grill can also be used to keep the food warm: by turning the thermostat control knob back to a lower position or by using the keep warm grill of the windshield.

Instruction manual

6. When grilling is finished, turn the thermostat to “0” (off position) and disconnect the grill from the mains supply socket.

CLEANING AND STORAGE

Caution:

Do not use wire brush or any abrasive items or liquids to clean the appliance.

Always remove the plug from the socket before cleaning the barbecue

1. Ensure that the appliance has completely cooled down
2. Then you should remove thermostat control knob and heating element from the tank, never immerse them in water. Never switch the heating element on when it is not placed onto the appliance.
3. Clean the tank, tray salvage dealer of fat and the grill pan with warm soapy water and dry afterwards.
4. Use damp cloth to clean the heating element.
5. Do not use dishwasher

Storage

After cleaning, the grill should be stored indoors in a dry location.

Instruction manual



Correct disposal of the unit

(Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection.

Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice