

LIVOO
Feel good moments
Instruction manual

Steam station



Reference: DOM405
Version : 1.4
Language: English



Instruction manual

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is available too on our website www.livoo.fr

General Instructions

**PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE
PARTICULARLY BEFORE THE FIRST USE.**

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Make sure the power used corresponds with the one indicated on the rating label and the socket has effective earth connection.
2. Use the iron only for needed use as described in the instruction manual.
3. Do not use this appliance outside
4. Close supervision is necessary when any appliance is used near children.
5. Burns can occur from touching hot metal parts, hot water or steam.
6. Keep the iron out of reach of children.
7. The iron should never be left unattended while it is connected to the supply mains.
8. The steam station must be used and rested on a flat, stable surface to avoid any risk of falling. When placing the steam station on its stand, ensure that the surface on which the

Instruction manual

stand is placed is stable.

9. The filling aperture must not be opened during use
10. The plug must be removed from the sock-outlet before the water reservoir is filled with water.
11. Unplug the steam station from the mains electrical supply :
 - Before cleaning
 - Before filling with water or emptying the water tank
 - Immediately after use
12. Do not pull the cord to unplug the appliance.
13. Never operate the steam station with damaged power cord or plug, or after it has fallen or been damaged in any way. To avoid the risk of electric shock, do not disassemble the iron, take it to a qualified serviceman for examination and repair.
14. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. (*)
15. Do not let cord touch hot surfaces.
16. To protect against a risk of electric hazards, do not immerse the iron in water or any other liquid.
17. The steam station must be used and rested on a stable surface.
18. The steam station must be connected to a ground socket.
19. The steam station is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
20. Never use the appliance with the damaged wall socket.
21. If you use the steam station with an extension cord, make sure it has a earth plug and that it supports the power of the unit. Pay attention that no one gets in the way.

Instruction manual

22. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
23. Do not handle the steam station or plug with wet hands.
24. Keep the steam station and its cord out of reach of children less than 8 years of age when it is energized or cooling down.
25. Only qualified and authorized persons are authorized to carry out repairs to your appliance. Any repairs not in accordance with standards could significantly increase the level of risk for the user!
26. Never add perfume, vinegar or other chemical liquid to the tank; it can damage the appliance.
27. Risk of burns: The soleplate becomes extremely hot during use. Do not touch it because you could get burned. Be careful when using the steam function as well. it could burn you.
28. The steam station must only be used with the stand provided.
29. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments
 - farm houses

Instruction manual

- by clients in hotels, motels and other residential type environments
- bed and breakfast type environments

(*) Competent qualified electrician: after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.


TECHNICAL SPECIFICATION

Voltage: 220-240V ~ 50-60Hz

Power: 2100W

DESCRIPTION

1. Iron temperature knob
2. On/off switch
3. Continuous steam button
4. Detachable water tank
5. Iron rest
6. Power cable
7. Cable + steam tube
8. Water indicator light
9. Ready indicator light
10. Heating indicator light
11. Power indicator light
12. Short steam button



USE

1. Take out the water tank (4) and fill it to the MAX level.
2. Turn on the steam station by turning ON/OFF switch (2), the Indicator light of power (3) is on.
3. Adjust the iron thermostat to the MAX for steam ironing.

NOTE: during the refilling operation, be careful that the water does not overflow.

Livoo
Feel good moments
Instruction manual

STEAM IRONING

1. Set the iron temperature to the "COTTON-LINEN" steam position, by turning the knob (1). All types of fabric can be ironed at this temperature.
2. Wait for the indicator light of steam (9) go on and wait for the steam button light (10) go off. Push button (3) on the iron to release continuous steam from the holes on the soleplate.
3. To stop continuous steam, please press the short steam button (12).
4. For short steam, press the short steam button (12). Release the button and the steam will stop.

NOTE: during initial operation of the iron, a few drops of water mixed with steam may come out of the soleplate until the temperature stabilizes. It is advisable to direct the first jets of steam onto an old cloth until a uniform stable jet of steam is obtained.

When you have used up all the water in the tank, do as follows:

- Switch off the on/off switch (2).
- Press the steam request button on the iron (3) so as to fully exhaust the steam supply from the tank.
- Put the iron back to the iron rest (5)
- Disconnect the power supply cable from the power outlet.
- Carefully refill the tank as above description.

CLEANING AND CARE

Be sure to always disconnect the appliance from the power outlet.

Normal tap water can be used. However, as hard water by its nature contains limestone, which may cause a build-up of lime scale in the tank, in hard water areas we recommend to use vinegar solution (75%water+25%vinegar) to clean the tank.

To clean the body of the appliance, simply use a moist cloth. Do not use solvents or detergents which may harm the body material.

LIVOO
Feel good moments
Instruction manual



Correct disposal of the unit
(Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection. Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr

LIVOO
61071
67452 Mundolsheim

- Non contractual illustration
- Product information is subject to change without prior notice.



Instruction manual