

Patio heater



Reference: DOM425
Version: 1.5
Language: English

User manual

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

General Instructions

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE
PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.



In order to avoid overheating, do not cover the heater.

1. Check that the mains voltage corresponds with the rating of the appliances.
2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
3. Children shall not play with the appliance.
4. Cleaning and user maintenance shall not be made by children without supervision.
5. Children of less than 3 years should be kept away unless continuously supervised.
6. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards

User manual

involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

7. In order to avoid overheating, do not cover the heater
8. To avoid the appliance's damage do not insert any items into the appliance.
9. Never put the front side of the appliance (grill) closer than 1 meter to the wall, furniture and other objects in the room as to avoid fire.
10. Always place and use the appliance in a ventilated and airy area
11. Never insert pens, pencils or any other objects through the grill when the appliance is turning on.
12. Never immerse the appliance or power cord into water.
13. Never use the appliance with wet hands.
14. Do not use the heater in the immediate surroundings of a bath, a shower or a swimming pool.
15. Never use the appliance on a damp surface/floor.
16. Never let the turned on appliance be unattended.
17. Never use the appliance with over tightened cord.
18. Never use the appliance with an extension cord.
19. Do not use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
20. The appliance must be installed at least 1,8 meter above the floor.
21. **WARNING:** The heater must not be used if the fan guard is damaged
22. Always unplug the appliance when not in use or before cleaning.

User manual

23. To disconnect the plug from outlet, do pull out by the cord.
24. Do not use any abrasive, chemical or alcohol-contained cleaners for cleaning the appliance.
25. Never use the damaged appliance or appliance with damaged cord/plug.
26. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard. (*)
27. Never use the appliance near or on the hot surfaces.
28. Give a high attention when the appliance is being used near the children.
29. Use only the appliance for its direct purpose.
30. Never expose the appliance to fall down or to be kicked.
31. Repair the appliance only in authorized service center. Do not repair the appliance by yourself.
32. Incorrect operation and improper handling can lead to malfunction of the appliance and injuries to the user.
33. The heating appliance must not be placed just below an electrical outlet
34. Prevent overheating of the appliance by keeping the air inlets and outlets clean and free of anything that may cause blockage. Check all inlets and outlets from time to time for accumulated dust.
35. Regarding the information pertaining to the installation, cleaning of the appliance, thanks to refer to the below paragraph of the manual.
36. This appliance is intended for household use and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments

- farm houses
- by clients in hotels, motels and other residential type environments
- bed and breakfast type environments.

CAUTION

Some parts of this product can become very hot and cause burns. Do not touch the grill or the cover during use. Particular attention has to be given where children and vulnerable people are present

WARNING: This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided

Pay attention that, no combustible material due to Wind or other environmental influences covers or obstructs the appliance, such as curtains, marquees, flags, plastic foil etc.

(*) Competent qualified electrician: after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

This instruction manual is available too on our website www.livoo.fr


TECHNICAL INFORMATION

Voltage	220V-240V
Power	2000W
Frequence	50Hz-60Hz
Appliance size	50 x 36 x 24.5 cm
IP	34
Classe	I
Weight	1.68kg

LIVOO

Feel good moments

User manual




HOW TO USE THE APPLIANCE

Before installing your appliance, you must disconnect the electrical supply at the circuit breaker.

Use the four screws to fix the bracket of the heater on the wall on a right position and then fix the heater on the bracket.

Hold up the product to make the back of the product wall-mounted holes into the four corresponding screws which are previously put on the wall. (As shown below)



In order to meet customer needs, the head of the product can be move up and down for 45-degree angle. (As shown below)



This heater requires installation with a ceiling height of at least 2,30 meters. Here are the spaces to respect in the room where you install the device

LIVOO
Feel good moments
User manual

The appliance is switched on by means of the pull switch. The slight vibration noticeable when the appliance is switched on will stop after a few seconds.

- Position 0: Stop
- Position 1: 650W (normal power)
- Position 2: 1300W (intermediate power)
- Position 3: 2000W (full power)

CLEANING AND STORAGE

Turn off the appliance and let the unit cool completely.

To keep the heater clean, the outer shell may be cleaned with a soft, damp cloth. After cleaning, dry the with a soft cloth

DO NOT use alcohol or abrasive product, to clean the appliance. This may cause damage o to the surface

DO NOT immerse the appliance in water.

Store it in a cool, dry location when not in use.



Correct disposal of the unit (Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream.

Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection.

Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr



LIVOO

61071

67452 Mundolsheim-FRANCE

- Non contractual illustration
- Product information is subject to change without prior notice.