

LIVOO
Feel good moments
Instruction Manual

Meat grinder



Reference : DOP224
Version : 1.4
Language : English



Feel good moments

Instruction Manual

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is available too on our website www.livoo.fr

GENERAL SAFETY INSTRUCTIONS

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed, we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Make sure your mains voltage corresponds to that specified on the appliance before plugging in. The appliance must be connected to an earthed mains safety socket.
2. To protect against electrical hazards, do not immerse the cord, plug, or appliance itself in water or other liquids.
3. Never let the machine operate unattended. Keep out of reach of children or incompetent persons.
4. The appliance is not intended to be operated by means of an external timer or separate remote control system.
5. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. (*)
6. Do not use the device:
 - if the grip or the power cable is damaged
 - in case of malfunction
 - if the device was damaged in any way
 - if it fell in the water

Instruction Manual

- if you dropped it
- 7. Never use the appliance near hot surfaces. Never move the appliance by pulling the cord. Do not wind the cord around the appliance or twist it.
- 8. Stand the appliance on a stable, flat surface.
- 9. Never use accessories which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
- 10. Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.
- 11. There is potential injury from misuse.
- 12. It is absolutely necessary to keep this appliance clean at all times as it comes into direct contact with food.
- 13. Regarding the instructions for cleaning surfaces in contact with food or oil, thanks to refer to the below paragraph "cleaning" in manual.
- 14. Regarding the instructions for the use of accessories, operation times and speed settings, thanks to refer to the below paragraphs.
- 15. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
- 16. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- 17. This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction



Feel good moments

Instruction Manual

concerning use of the appliance in a safe way and if they understand the hazards involved.

18. Children shall not play with the appliance.
19. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
20. Accessories, other than those supplied with the appliance, shall include instructions for their safety use.
21. This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments
 - Farm houses
 - By clients in hotels, motels and other residential type environments
 - Bed and breakfast type environments

(*) **Competent qualified electrician:** after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

SPECIFICATIONS

Voltage : 220-240V~ 50-60Hz

Power : 400W

Maximum continuous operating time (KB): 15 minutes

DESCRIPTION

Livoo

Feel good moments

Instruction Manual




ASSEMBLING YOUR APPLIANCE

- . Check that voltage indicated on the rating label corresponds to the mains voltage in your home.
- . Wash all parts (except motor housing) in warm soapy water.

Instruction Manual

1. Hold the head and insert it in the inlet with one hand, revolve toward left and insert taking care to match the slot. Then press the locking knob and turn to the left to lock and (fig. 1 and 2).
2. Place the feed screw into the head, long end first, by turning the feed screw slightly until it is set into the motor housing (fig.3).
3. Place the cutting blade onto the feed screw shaft with the blade facing the front as illustrated (fig.4). If it is not fitted properly, meat will not be ground.
4. Place the desired cutting plate next to the cutting blade, fitting protrusions in the slots (fig.5).
5. Support or press the center of the cutting plate with one finger then screw the fixing ring until tight with another hand (fig.6). Do not over tighten.



7. Place the hopper plate on the head and fix into position.
8. Locate the unit on a stable surface. The air passage at the bottom and the side of the motor housing should be kept free and not blocked.

LIVOO

Feel good moments

Instruction Manual

MINCING MEAT

Cut all foods into pieces (Sinewless, boneless and fatless meat are recommended), in approximate size:20 x 20mm so that they fit easily into the hopper opening.

Plug in and press "ON" switch button.

Feed foods into hopper plate hole. Use only the food pusher

After use, switch the unit off and unplug it from the power supply.

REVERSE FUNCTION


1. In case of jamming, switch the appliance off by pressing "ON OFF" button, then press reverse switch.
2. Feed screw will be rotating in the opposite direction, and the head will get empty.
3. If it doesn't work, switch the unit off and clean it.

MAKING KEBBE

Place kebbe attachments onto the feed screw shaft together, fitting protrusions in the slots (fig.8).

Screw fixing ring into place until tight. Do not over tighten (fig.9 + fig.10).

Form Kebbes as illustrated below and deep fry:



EXAMPLES OF RECIPES

Instruction Manual

FOR STUFFING

- Mutton 100g
- Olive oil 1 ½ tablespoon
- Onion (cut finely) 1 ½ tablespoon
- Spices to your taste
- Salt to your taste
- Flour 1 ½ tablespoon

1. Mince mutton once or twice.
2. Fry onion until brown and add minced mutton, all spices, salt and flour.


MEAT COATING

- Lean meat 450g
- Flour 150-200g
- Spices to your taste
- Nutmeg (finely cut) 1
- Powdered red pepper to your taste
- Pepper to your taste

1. Mince meat three times and mix all ingredients together in a bowl. More meat and less flour create better consistency and taste.
2. Grind the mixture three times.
3. Disassemble by reversing the assembling steps from 5-3 to remove the cutting plate and cutting blade.

MAKING SAUSAGE

Before starting, please assemble sausage attachment as per following (fig.11)



1. Never prepare very thick sausages in order to avoid any pressure on casing.
2. Note: soak the casings for around 10-15 minutes in warm water to make them flexible.
3. Connect appliance, switch it on.
4. Push the ingredients into the hopper plate hole and slowly take off the casing from the attachment tip as it fills.

LIVOO

Feel good moments

Instruction Manual

5. Twist the casing to shape the sausages.


MAKING BISCUIT

Before starting, please assemble biscuit attachment as per previously mentioned instructions.

1. Select the desired form of biscuit and place the mixture on the hopper plate.
2. Connect appliance, switch it on.
3. If necessary, press on the preparation with the pusher. Do not engage fingers.
4. Hold the dough elongated when out and cut to desired length.

CLEANING AND STORAGE

1. Make sure that the motor has stopped completely.
2. Disconnect the plug from the power outlet.
3. Disassemble by reversing the steps from 6 to 1 figures.
4. If the fixing ring is not easily removed by hands, please use tools.
5. To remove the cutting plate easily, place a screwdriver between the cutting plate and the head as illustrated and lift it up (fig.12 + 13).
6. Remove food scraps of meat, etc. Wash each part in warm soapy water.
7. Never immerse the motor housing in water, but only wipe it with a damp cloth.
8. Do not put accessories into dishwasher.
9. A bleaching solution containing chlorine will discolor aluminum surfaces.
10. Thinners and petrol will crack or change the color of the unit.
11. Wipe all the cutting parts with a soft cloth and metal parts with grease or vegetable oil-wet cloth to prevent them from rusting.



LIVOO

Feel good moments

Instruction Manual



Disposal of this product
(Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems)

The European Directive 2012/19/EU on Waste Facilities Electrical and Electronic (WEEE)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product or their local authority office, for details of where and how they can take this item for environmentally safe recycling.



Pour en savoir plus :

www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice