

DomoClip®

User manual

Battery free digital Scale



Reference : DOS163
Version : 1.1
Language : English

WWW.DOMOCLIP.COM

DomoClip®

User manual

You have purchased a product DOMOCLIP brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is also available on our website www.domoclip.com

SPECIAL MEASURES

Warning:

1. The scale is high precision measuring device. Never jump or stomp on the scale or disassemble it and please handle it carefully to avoid dropping when moving it.
2. The scale is for family use only and not suitable for professional use.
3. If any problem, please contact the local dealer or our company directly by phone or E-mails.


Information :

To ensure accuracy, we suggest you take measurement at a fixed time every day (e.g.8:00am-9:00pm).

DESCRIPTION

- | | |
|--|---|
| 1. High precision strain gauge sensors system. | 5. 5 mm tempered safety glass platform |
| 2. Capacity: 180kg/396lb | 6. Automatic power generation control |
| 3. Unit: kg-lb | 7. Battery-free technology |
| 4. Mini effective weight: 6kg | 8. Auto zero resetting / Auto power off |
| | 9. Low power / over-load indication |

USING YOUR APPLIANCE



DomoClip®

User manual


1. One quick stamping on the Magic-Start button will generate power weighing, please wait until "0.0" appears.
2. Choose the unit on the back of the appliance: kg or lb
3. Place the scale on hard and flat surface. Clean floor is better.
4. The scale powers off automatically after one minute.
5. Don't step on the scale until "0.0" appears.

Caution

1. Low battery indication: when the screen indicates image below, it will turn off automatically after few seconds. Simply reload it by stamping on the U-power button.



2. "Err" showed on LCD indicates overload (more than 180kg).



3. Unit exchange (kg/lb)



Under weight mode, press the unit key to choose the unit, the key is on the back of the scale.

Note: please set the unit before weighing. It could not change the unit while weighing.

CLEANING AND STORAGE

Please use soft tissue with alcohol or glass cleaner to clean the surface if it is dirty. No soap or other chemicals. Keep it away from water, heat and extreme coldness.

DomoClip®

User manual



Correct disposal of the unit

(Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection. Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr

DOMOCLIP

BP 61071

67452 Mundolsheim - FRANCE

- Non contractual illustration
- Product information is subject to change without prior notice.