

Foldable travel hair dryer



Reference : DOS165
Version : 1.4
Language : English



Instruction Manual

Thank you to have purchased a product brand LIVOO. We take great care in design, ergonomics and simple use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is available too on our website www.livoo.fr

General Instructions

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE
PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Before use check that the voltage of your wall outlet correspond to the rated voltage manner.
2. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard (*).
3. Note when unpacking the appliance:
DANGER for children. Danger to life through suffocation!
4. Keep the packaging material away from children
5. To prevent a life-threatening electrical shock:



Keep the appliance away from water! Warning: Do not use this product near bathtubs, basins or other vessels containing water

Instruction Manual

6. When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off.
7. Never immerse the appliance in water or in any other liquids.
8. Do not use the appliance while taking a bath.
9. Water and other liquids represent a danger. If the appliance falls into water, pull out the main plug immediately.
10. Do not reach into the water!
11. Pull the mains plug from the socket:
 - When a disturbance occurs.
 - Before you clean the appliance.
 - If you will not be using the appliance for a longer period.
 - After each use.
12. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
13. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
14. Children shall not play with the appliance.

Instruction Manual

15. Cleaning and user maintenance shall not be made by children without supervision.
16. Make sure that the cable is not pinched in cupboard doors or pulled over hot surfaces. Otherwise the cable insulation may become damaged.
17. Never cover the fan or air inlet. Ensure that the air inlet remains free from fluff and hairs. Danger of fire!
18. Also note that a blocked air inlet causes the hair dryer to switch off automatically.
19. Keep jewelry chains away from the air inlet so that they are not drawn into the appliance.
20. The cable must not be twisted, pulled, kinked or wound around the dryer. If the cable is twisted, untwist it before use.
21. Before use check the cable for damages.
22. Regularly check the appliance and above all the cable for defective and porous locations.
23. To avoid breaks never wind the cable around the appliance.
24. Watch out that the plug never contacts hot parts of the appliance. Only use the appliance when the appliance, cable and plug show no sign of damage. Never use a defective appliance.
25. Never try to repair a defective appliance yourself.

Instruction Manual

26. Danger of burning! The air outlet or attachments can become very hot. Do not touch them during operation. Allow them to first cool before changing them.
27. Danger of fire due to high temperatures. Do not use on artificial hair.
28. Danger of death due to electrical shock!
Never touch hair dryer with wet hands when connecting it to the electrical mains or during mains operation!
29. Overheat protection!
Should the appliance overheat, i.e. due to blockage of air intakes, the appliance will switch itself off automatically. Please switch off the appliance entirely and let it cool for about 6 to 15 minutes. Once cooled down, the appliance can be used again.
30. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments
 - farm houses
 - by clients in hotels, motels and other residential type environments
 - bed and breakfast type environments

(*) Competent qualified electrician: after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

Instruction Manual

WARNING

The following should be noted to ensure trouble-free operation:

Only operate the appliance according to the details on the nameplate.

Do not subject the hair dryer to temperatures below 10°C and above 35°C

Thoroughly clean the appliance after each use

Allow the appliance to run for approx.3-5 minutes before using it for the first time. During this time a slight odor may arise due to the manufacturing process. This is harmless and only occurs when first used.

Never place the appliance into water or any other liquid.

TECHNICAL DATA

Power: 1200W

Power supply: 120-230V~ 50-60Hz


CLEANING AND STORAGE

1. Always ensure that hair dryer is disconnected from the mains supply before cleaning.
2. Use a damp cloth for cleaning and wipe dry. This will help preserve the original finish of your hair dryer.
3. Abrasive cleansers should not be used.


Instruction Manual

4. After a while of use, you should take the inlet apart and clean it .Operate method: Push the air inlet grille, then move to the left until it out of hair dryer.
5. After finishing clean, please insert the air inlet grille into the tail of hair dryer and move to the right until locked at the right position.
6. Frequently clean our any hair or fluff that becomes stuck in the inlet filter
7. Cleaning can avoid overheating

DESCRIPTION



Instruction Manual



USE

1. Always ensure the switch is set to OFF position before plugging the unit into the power outlet.
2. Use the high setting for drying hair, and use low setting for styling.
3. If the hair dryer stop for any reason, turn it off at once and let it cool down.
4. Switch control

0=OFF Position

1=HIGH: high speed

2=HIGH: high hot temperature

5. The concentrator can be used on or without.
6. Switch off when finish using, and then remove the plug from the socket.
7. You can fold up for an easier transport

NOTE: The voltage switch allows to use the hair dryer on either 120 or 230 V.

Most countries will require the hair dryer to be set at the 230V position. In the USA, set the hair dryer at the 120V position.

The hair dryer should be unplugged to the alternative current outlet. The switch should be placed in the OFF position (0).

The adjustment can be made by using a screwdriver or similar instrument to turn the voltage selector to the appropriate voltage.

CAUTION! Always check that the selected voltage corresponds to that of the mains. Never use the unit on 230V if the voltage switch is set to 120V

LIVOO
Feel good moments

Instruction Manual



**Correct disposal of the unit
(Electrical and Electronic Equipment)**

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)



The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream.

Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection.

Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice