

LIVOO

Feel good moments

Instruction manual

Curling iron 3 heads



Reference : DOS181
Version : 1.5
Language : English

WWW.LIVOO.FR



Instruction manual

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

GENERAL INSTRUCTIONS

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE PARTICULARLY BEFORE THE FIRST USE.

A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Before use, make sure that the voltage of your wall socket meets the requirements of the rated voltage.
2. If the cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid hazard (*).
3. When unpacking the unit:
DANGER for children. Danger of death by suffocation! Keep the packaging material out of the reach of children.

Instruction manual

CAUTION:

4.  Do not use this device in a bathtub, shower, or water-filled reservoir.
5. Unplug the curling iron after use when using it in a bathroom as water in the vicinity is a hazard even when the straightener is turned off.
6. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice
7. Never open the housing of the appliance. There is danger of electric shock.
8. Do not use the device while taking a bath.

Instruction manual

9. Water and other liquids are a hazard. If the unit falls into water, unplug it immediately.
10. Unplug:
 - When an incident occurs.
 - Before cleaning the unit.
 - If you do not use the unit for a long time.
 - After each use.
11. This appliance may be used by children aged 8 years or older and by persons with reduced physical, sensory or mental capabilities or without experience or knowledge, if they are properly supervised or if they have been given instructions on how to use the appliance safely and if the risks involved are understood.
12. Children should not play with the appliance.
13. Cleaning and maintenance by the user must not be carried out by children without

Instruction manual

supervision. Avoid children playing with or touching the curling iron when using it or when it is cooling down.

14. Make sure the cable is not trapped in cabinet doors or laid on hot surfaces. Otherwise the cable insulation may be damaged.
15. The cable must not be twisted, pulled, pinched or wrapped around the straightener. If the cable is twisted, untwist it before using the Multistyler.
16. Check the cable for damage before use.
17. Check the device regularly, especially the cable, there should be no defective or porous areas.
18. To avoid cuts, never wrap the cable around the unit.

Instruction manual

19. Make sure that the plug never comes into contact with any of the hot surfaces of the unit.
20. Do not use the device until the device, cable and plug show no signs of damage. Never use a defective unit.
21. Never attempt to repair a defective unit yourself.
22. Risk of burns! The plates heat up very quickly, do not touch them. Keep them away from your skin. Let them cool down after use.
23. Do not leave the unit unattended when not in use.
24. Do not insert any objects into the unit.
25. This appliance is intended for home use only. Any other use (professional, commercial, etc.) is excluded.

Instruction manual

26. Risk of fire due to high temperatures. Do not use on artificial hair or hair extensions.

27. Risk of electric shock!

Never touch the curling iron with wet hands when plugging it in or during use!

28. Protection against overheating!

If the unit overheats, please turn it off completely and let it cool down for 6 to 15 minutes. Once cooled down, the unit can be used again.

29. Burn hazard. Keep the unit out of the reach of young children, especially when using and cooling it.

30. When connected to power, never leave the unit unattended.

31. Always place the unit with the bracket, if present, on a flat, stable, heat-resistant surface.

Instruction manual

32. This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments
- farm houses
- by clients in hotels, motels and other residential type environments
- bed and breakfast type environments

(*) **Competent qualified electrician:** after sales department of the producer or importer or any person who is qualified, approved and competent to perform this kind of repairs in order to avoid all danger. In any case you should return the appliance to this electrician.

This instruction manual is available too on our website www.livoo.fr

Instruction manual

WARNINGS

To ensure proper use of the unit:

Follow the instructions on the unit's nameplate.

Keep the unit clean after each use.

Leave the unit on for about 3 to 5 minutes before using it for the first time. During this process, an odor due to manufacturing residues may be released. This is normal and only happens during the first use.

TECHNICAL FILE

Voltage: 110V-240V~ 50-60Hz


Power: 130W

CLEANING AND MAINTENANCE

1. Unplug the curling iron, and let it cool down.
2. Clean all parts of the unit with a damp cloth.
3. Never use solvents or abrasive products.
4. Use the hanging ring to hang your device

DESCRIPTION

- A. Power cord
- B. On / Off button
- C. Operation LED
- D. Temperature control knob
- E. Opening clip
- F. Heating tube
- G. Aluminum plate





Instruction manual

USE

1. Plug in the unit and press the on/off button, the light will come on and flash. Set the desired temperature with the dial provided. The light will turn blue when the temperature is reached. Always unfold the metal base of the iron and rest it on the iron so as not to burn the base on which the appliance rests.
2. Use the curling iron on dry hair. Detangle your hair beforehand and always curl from the roots to the ends.
The slight sizzle and smoke is caused by the evaporation of sebum or excess water from the hair or from hair products applied to the hair.
3. Select a strand of hair and place it between the plates. Close the iron on the strand for a few seconds depending on the nature of your hair.
Release the iron and repeat the process along the entire length of the hair, closing the iron on the last wave obtained for a more harmonious result. Let the hair cool down before working on it.

Note : keep a distance of 3 to 5 cm from the roots or your scalp to avoid any burns.

4. After use, press the on/off button and unplug the unit. Allow the unit to cool down completely before storing.

Note : The curling iron gets very hot during use, you should keep it away from your skin to avoid any burns.

Instruction manual



Correct Disposal of this product

(Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

The European Directive 2012/19/EU on Waste Facilities Electrical and Electronic (WEEE)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product or their local authority office, for details of where and how they can take this item for environmentally safe recycling.



LIVOO

BP 61071

67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice