

Connected Jump rope



Reference: DOS189
Version : 1.4
Language : English

WWW.LIVOO.FR

You have purchased a product LIVOO brand and we thank you. We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is available too on our website www.livoo.fr

GENERAL INSTRUCTIONS

PLEASE, TAKE TIME TO READ WELL THE INSTRUCTIONS FOR USE PARTICULARLY BEFORE THE FIRST USE. A misuse of the appliance can damage it or hurt the user. Assure that you use the appliance for the use for which it is designed; we refuse any responsibilities as for the damages by an incorrect use or a bad manipulation.

1. Do not put the rope in very wet or hot environment.
2. Avoid hitting or dropping the rope violently, otherwise damage may occur.
3. Treat the rope with care as it is an electronic instrument.
4. Do not immerse the handle into water or use it while raining, because it is not water-proof and damage may occur to the built-in electronic device.
5. The rope is only used for the purpose of physical exercise. Do not use it for other purposes.
6. Be careful when using the rope to avoid any injuries, and children under 10 are suggested to use the rope under the watch of parents.

FEATURES

Product Size	Φ23 x 164mm
Product Weight	0,18 kg
LCD Display	19,6 x 8,1 mm
Power	3,7 V Rechargeable Lithium Cell Battery 60mAh
USB cable	1 meter micro USB cable
Max. Jumps	9999 times
Max. Time	99 Mins 59 Seconds
Min. Jump	1 time
Min. Time	1 second
Auto off Time	60 seconds


PRODUCT DESCRIPTION



1. LCD display
2. Power on/ Power off/ Reset/ Mode Button
3. Micro USB charging port
4. PVC steel rope

Note: The jump rope is installed with 3.7 V lithium cell battery, please make sure to charge the USB battery for 1 hour before usage.
60 seconds


PRODUCT LCD display



Display in different modes



1. Countdown Timer Mode



2. Countdown Number Mode





3. Free Skipping Mode

SET UP

The jump handle and the rope are packed separately in the box, please follow the below steps to install the rope and adjust the length accordingly.

Important Note: To avoid inaccurate, please make sure the longer rope is installed in the inside part of the handle.



USE

Installation of the Jump Rope


1. Before starting using the jump rope, please download the App: Skipjoy from App store or Google play.
Or you can scan below QR code to download the App.



2. When you install the application, please make sure that your bluetooth is enabled under IOS and your location is enabled under Android.

Note: Google requires that all smartphones running Android Ver. 6.0 or higher must request location authorization where applicable.

No private information will be collected by the application. You can also refer to this official document, for more information: <https://source.android.com/devices/bluetooth/ble>





Allow Bluetooth for iOS



Allow location for Android

3. Open Skipjoy App, fill in your personal info, and start the App



LIVOO

Feel good moments

User manual

4. Skipjoy will automatically pair the jump rope, you can check the main interface on the App to check the status of connection.
 - “Connected” shown on the main interface means successful pairing.
 - “Disconnected” shown on the main interface means unsuccessful pairing.
 - Press “Mine” --> “Device” --> “+” to add the device manually
5. Click the mode you need on the main interface on the App to start your jumping;




Jump Modes


3 different jump modes are available: Free jump / Jump with time countdown / Jump with countdown of a defined number of jumps

- Keep pressing the button for about 3 seconds to shift the mode you need.
- You can also choose the mode from the application

Free Jumping



Jump the rope freely and there is no limit on time and number of jumps





Time countdown Jumping:

- set the total jumping time.
- options for time can be set on the application: 30 sec, 1 min, 5 min, 10 min, and customized time
- Without the App, the rope will use the last countdown setting of time from the application.



Numbers countdown Jumping:

- set the total jumps;
- options for number of jumps can be set on App: 50, 100, 500, 1000 and customized number of jumps.



Countdown Number	50skips
	100skips
	500skips
	1000skips
	CUSTOMIZE

Connected



Offline storage function

Without the running of App, the data of your jumping will be recorded temporarily by the rope and synchronized with the App after re-connection.

Reset the rope

Press the button on the back of the LCD display for 8 seconds, the rope will be reset. The LCD will show all the signals for 2 seconds and then shut down. Press the button again to enter the normal use

Battery usage

The skipping rope is equipped with a built-in Lithium-ion battery that can withstand normal use for approximately 25 days (calculated based on 15 minutes of daily use, actual usage time will vary depending on the environment and usage time).

Typical standby time is 33 days (manufacturer's experimental data).

Charging your device

If the signal appears on the display, please recharge the cord using a normal cell phone charger with a standard Micro USB socket.

During the charging process, the battery signal on the LCD screen will flash until the battery is full.

Important:

For best battery life, do not leave the jump rope with a discharged battery for a long period of time. It is suggested to charge the skipping rope when the battery is low.

When you do not use the skipping rope for a long period of time, we recommend that you charge the battery at least once a month.

Procedure to observe for battery's end of life

The appliance batteries must be removed before discarding the equipment. Please follow the procedure below:

Ensure that your appliance is disconnected so as to reduce any risk of electrical shock. Discharge the batteries fully.

Remove the protection cover situated in a location where you connect the mains voltage adapter and it is removed so as to access the batteries compartment. Carry a screwdriver to remove the screw.

Remove the batteries from the equipment. Cut the cables and tab connecting the batteries in the printed circuit and remove them.

ATTENTION: THESE NI-MH CELLS MUST BE RECYCLED OR ELIMINATED IN ACCORDANCE WITH THE EQUIPMENT SCRAPPING.

Do not burn, dismantle, crush or break out the batteries because they can release toxic substances.

Do not expose them to extreme temperatures.

Drop them in the batteries recycling bins designed for this purpose or return them to your retailer.

EU DECLARATION OF CONFORMITY

We
DELTA
BP61071
67452 Mundolsheim – France

Herewith declare under our sole responsibility, that the radio equipment

Vlogging video kit
DOS189 (Frequency range 2402 – 2480MHz)

Fulfils the essential requirements of the Directive 2014/53/UE

The following standards were applied:

Radio:
EN 300 328 V2.2.2

EMC:
EN 301 489-1 V2.2.3
Draft EN 301 489-17 V3.2.2

Health and Safety:
EN 62479 : 2010

Mundolsheim, 12/02/2021



Correct Disposal of this product
(Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems)

The European Directive 2012/19/EU on Waste Facilities Electrical and Electronic (WEEE)
This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product or their local authority office, for details of where and how they can take this item for environmentally safe recycling.



Pour en savoir plus :
www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim - FRANCE

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice