

Bluetooth[®] compatible selfie stick



Reference : TEA260
Version : 1.4
Language : English

LIVOO

Feel good moments

User manual

Thank you to have purchased a product brand Livoo. We take great care in design, ergonomics and simple use of our products. We hope that this product will give you complete satisfaction.

PLEASE READ ALL INSTRUCTIONS CAREFULLY

This instruction manual is also available on our website www.livoo.fr

SAFETY INSTRUCTIONS

The product is not suitable for children under 3 years because of choking hazard.

Contains small parts, in order to avoid swallowing, please ensure any use by children is undertaken with adult supervision.

Do not expose the device to abnormally high or low temperatures. Store the device cool (at room temperature) in a dry and dust-free location and never expose the product to high temperatures or direct sunlight. This product is not suitable for use under water or in wet conditions. Please ensure your gimbal is kept dry at all times.

If you think this product is damaged in any way, please do not use the product.

To avoid the risk of electric shock, do not insert the power cord with wet hands.

Ensure the gimbal is not obstructed during use as this may lead to damage of the internal motor mechanism.

Please dispose of the waste and residues at the end of the service life of the product according to local laws and regulations.

In the unlikely event of overheating, smokes or unpleasant odours coming from the unit, disconnect it immediately from the charging cable.

Never attempt to access or replace the built-in battery.

Protect the product from falls, shock and impact.

MAIN SPECIFICATION


- Adjustable angle: 90° horizontal/vertical
- Rechargeable battery: 400mAh
- Bluetooth® compatible
- Adjustable support for any type of Smartphone
- Operating time: 2-3 hours
- Charging time: 2 hours
- Remote control until 10 meters
- Extend size up to 52 cm

LIVOO

Feel good moments

User manual

DESCRIPTION



OPERATION

To ensure your gimbal configures itself correctly for use, always place your smartphone into the holder before switching the device on.

Note : For best stabilization performance, when inserting the smartphone into the clamp, always try to place it in the center of the clamp for the best balance.

On Off

LIVOO

Feel good moments

User manual

On: Press and hold the button on the pole stick for 2-3 seconds until it flashes.

Off: Press the button for 5-6 seconds.

Charge

To charge the selfie stick, use the supplied USB / micro USB cable.

Plug the micro USB end into the stick port and the USB end into a PC's USB port, or USB power adapter (not included).

The LED indicator confirms the battery is charging.

Bluetooth® pairing

Before use, pair your selfie stick with your smartphone.


Long press the shutter button for 3 seconds to activate the remote.

The LED will illuminate and Bluetooth® pairing mode will start automatically.


Search for new Bluetooth® devices in your smartphone Bluetooth settings menu.

The remote will appear as "TEA260".

When the Bluetooth® pairing is complete the LED will turn off.



Place the Smartphone




Position the smartphone in the holder provided for this use.

Selfie stick or tripod

LIVOO


Feel good moments

User manual



Extend the Selfie stick or set up the stand.


Switch on the gimbel



With the smartphone in position, turn on the stabilizer by long-pressing the power button for 3 sec.

The stabilizer will activate and configure itself.

Changing the orientation



Short-press the power button to change the position of the gimbal from horizontal to vertical.

Please note: If you turn the position several times, the bracket will snap in and the gimbal will automatically switch off.

Switch off the gimbal

Turn off the stabilizer by long-pressing the power button for 3 sec.

Shooting

Press the trigger button on the pole. One press is enough to take a picture.


Change the remote control battery

To change the battery, open the remote control using the recess on the side. You will need a new CR1632 battery.

LIVOO

Feel good moments

User manual



1. Extend the selfie stick
2. Slide the remote upwards to remove it
3. Open the top cover of the remote control
4. Change the CR1632 battery
5. Close the top cover
6. Slide the remote back into position

EU DECLARATION OF CONFORMITY

We
DELTA
BP61071
67452 Mundolsheim – France

Herewith declare under our sole responsibility, that the radio equipment

Bluetooth® compatible stabilizer selfie stick
TEA260 (Frequency range 2402MHz-2480MHz)

Fulfils the essential requirements of the Directive 2014/53/UE

The following standards were applied:

Radio:
EN 300 328 V2.2.2 (2019-07)

EMC:
Draft EN 301 489-17 V3.2.2 (2019-12)
EN 301 489-1 V2.2.3 (2019-11)

Health and Safety:
EN 50663:2017; EN 62479:2010
EN 60950-1: 2006+A11: 2009+A1:
2010+A12: 2011+A2: 2013

Mundolsheim 15/11/2020

LIVOO

Feel good moments

User manual



Correct disposal of the unit (Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/UE on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection. Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :
www.quefairedemesdechets.fr

LIVOO

BP 61071

67452 Mundolsheim

- Non contractual illustration
- Product information is subject to change without prior notice.