

LIVOO
Feel good moments
Instruction Manual

Battery charger phone holder



Reference : TEA288
Version : 1.4
Language : English

Instruction Manual

Thank you for buying our LIVOO product.

We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is also available on our website www.livoo.fr

SAFETY ADVICES

BEFORE USING THE APPLIANCE FOR THE FIRST TIME, PLEASE READ CAREFULLY THESE INSTRUCTIONS BEFORE USING THE APPLIANCE AND SAVE IT FOR ANY FURTHER NEED.

- Do not dismantle, open or shred secondary cells or batteries.
- Keep batteries out of the reach of children.
Battery usage by children should be supervised. Especially keep small batteries out of reach of small children.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Do not expose cells or batteries to heat or fire. Avoid storage in direct heat.
- Do not short-circuit a cell or a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other meal objects.
- Do not remove a cell or battery from its original packaging until required for use.
- Do not subject cells or batteries to mechanical shock.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Do not use any charger other than that specifically provided for use with the equipment.
- Observe the plus (+) and minus (-) marks on the cell, battery and equipment and ensure correct use.
- Do not use any cell or battery which is not designed for use with the equipment.
- Do not mix cells of different manufacture, capacity, size or type within a device.
- Always purchase the battery recommended by the device manufacturer for the equipment.
- Keep cells and batteries clean and dry.
- Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.
- Do not leave a battery on prolonged charge when not in use.
- After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
- Retain the original product literature for future reference.

Instruction Manual

- Use the cell or battery only in the application for which it was intended.
- When possible, remove the battery from the equipment when not in use.
- Never try to connect simultaneously both grips by means of the cable of connection, this manipulation could cause big damage in the power bank, cause a risk of electric shock or fire.
- In case of dysfunction, entrust your power bank to a specialist.
- No pieces can be repaired or replaced by the user.
- Maintain your power bank shielded from the rain, from the water or from the humidity.
- Recharge the appliance every 3 months in case of prolonged not use or charge and do not discharge the appliance at the same time.
- Dispose of properly.

Please fully charge the appliance between 5 to 6 hours by using the USB / MICRO-USB before the first use.

SPECIFICATIONS


Battery: 3.7V 4000MAH

Input Jack: Type-C DC5.0V/2.0A


Output Jack: USB DC5.0V/2.0A

Output Jack: Type-C

DESCRIPTION




Instruction Manual




USE

- Open the battery charger like above shows
- Pull out the type-C jack to suit the phone jack then put on (if your phone has a Type C socket) , then it's OK to charging
- Then put the phone on the clip like below picture.



- If your phone does not have a Type C output, simply connect your USB charging cable (not supplied) to the USB output of the backup battery and then connect the other end (microphone/lightening tip) of your cable to your phone.



- It is also phone holder

Instruction Manual

CORRECT DISPOSAL OF THE UNIT

Disposal of batteries and accumulators (Applicable in the European Union countries and in the other European countries having systems of selective collection)



This symbol, affixed on batteries and accumulators or on packaging, indicates that batteries and accumulators supplied with this product must not be treated as simple household waste.

By assuring you that these batteries and accumulators are discarded in a appropriate way, you participate actively in the prevention of the negative consequences which their ill-treatment could cause on the environment and on the human health. The recycling of materials contributes besides to the conservation of natural resources.

For the products, which, for safety reasons, of performance or integrity of data require a permanent connection in a battery or in an accumulator, it will be advisable to move closer you to check with technical service qualified to make its replacement. By bringing back your electric device at the end of life to an appropriate point of collection you make sure that the battery or the incorporated accumulator will be correctly treated.

For all other scenarios and to remove battery or accumulators in complete safety of your appliance, refer to the user manual.

Bring back batteries or worn accumulators to the point of collection suited for the recycling.

For any further information about the recycling of this product or batteries and accumulators, you can contact your municipality, your local waste reception center or the point of sale where you bought this product.



Correct disposal of the unit (Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection. Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.



Pour en savoir plus :

www.quefairedemesdechets.fr

LIVOO
BP 61071
67452 Mundolsheim

- Photo no contractual.
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice.