



Batterie
Externe
Écologique
POWERECO 10 000



1. Précautions

Merci de lire le manuel d'utilisation avant usage afin de tirer pleinement partie de votre Powereco

- Ne pas percer, jeter ou plier le produit.
- Ne pas jeter la batterie au feu.
- Ne pas exposer la batterie à une chaleur excessive.
- Ne pas court-circuiter la batterie avec du plomb ou d'autres produits en métal.
- Ne pas transporter ou entreposer la batterie avec des objets en métal.
- Éviter l'électricité statique, les forts champs magnétiques et les radiations.
- Ne pas désassembler la batterie ou changer sa structure.
- Arrêter d'utiliser la batterie en cas d'odeur inhabituelle ou de distortions du produit, ou autres anomalies.
- Garder hors de portée des enfants.
- Utiliser la batterie dans un endroit sec.

2. Caractéristiques produit

Batterie Externe

Capacité : 10 000 mAh

Dimensions : 63 x 94 x 24mm
Poids : 190G

Ports USB : 2 x 2.1A^{out}
Port Micro-USB : 5V/2Aⁱⁿ
Port USB-C : 5V/2A^{out}

Temps de charge :
- 4 heures avec un chargeur secteur 5V/2A

Indicateur de charge : 4 LEDs


3. Comment recharger sa Powereco

Branchez la Powereco sur un chargeur secteur délivrant 5V/2A en utilisant le câble Micro-USB fourni avec la batterie.

4. Comment recharger ses appareils

Branchez un câble adapté à votre appareil sur le port USB de la Powereco puis allumez la en pressant le bouton Power

5. Diagramme produit



Port USB
Indicateurs LED
Port Micro-USB
Port USB-C
Port USB 2

Statuts de l'indicateur LED

1 LED allumée : 10% à 40% de charge
2 LEDs allumées : 40% à 65% de charge

3 LEDs allumées : 65% à 85% de charge
4 LEDs allumées : 85% à 100% de charge

@ contact@x-moove.com

 x_moove

 X-Moove

 www.xmoove.fr

Front : French



Ecological
Power
Bank
POWERECO 10 000



1. Precautions

Please read the following manual before use in order to take full advantage of your Powereco.

- Do not puncture, discard or bend the product.
- Do not throw the battery into the fire.
- Do not expose the battery to excessive heat.
- Do not short-circuit the battery with lead, or other metal products.
- Do not transport or store the battery with metal objects.
- Avoid static electricity, strong fields, magnetic and radiation.
- Do not disassemble the battery or change its structure.
- Stop using the battery in case of unusual smell or product distortions, or other anomalies.
- Keep out of reach of children.
- Use the battery in a dry place.

2. Product characteristics

Power Bank

Capacity : 10 000 mAh

Dimensions : 63 x 94 x 24mm
Weight: 190G

USB Ports : 2 x 2.1A^{out}
Micro-USB Port : 5V/2Aⁱⁿ
USB-C Port : 5V/2A^{out}

Charging time :
- 8 hours with a wall plug - 5V/2A

Charging indicator : 4 LEDs


3. How to charge your Powereco

Connect the Powereco to a wall plug 5V/2A using the Micro-USB cable supplied.

4. How to recharge your devices

Connect a cable suitable for your device to the USB port of the Powereco the charge will start Automatically.

5. Product diagram



USB Port
LED Indicator
Micro-USB Port
USB-C Port
USB Port 2

LED Status

1 LED : 10% to 40% charged
2 LEDs : 40% to 65% charged

3 LEDs : 65% to 85% charged
4 LEDs : 85% to 100% charged

@ contact@x-moove.com

 x_moove

 X-Moove

 www.xmoove.fr

Back : English