



1. Précautions

- Merci de lire le manuel d'utilisation avant usage afin de tirer pleinement partie de votre X-Moove Rugged
- Ne pas percer, jeter ou plier le produit.
  - Ne pas jeter la batterie au feu.
  - Ne pas exposer la batterie à une chaleur excessive.
  - Ne pas court-circuiter la batterie avec du plomb ou d'autres produits en métal.
  - Ne pas transporter ou entreposer la batterie avec des objets en métal.
  - Eviter l'électricité statique, les forts champs magnétiques et les radiations.
  - Ne pas désassembler la batterie ou changer sa structure.
  - Arrêter d'utiliser la batterie en cas d'odeur inhabituelle ou de distortions du produit, ou autres anomalies.
  - Garder hors de portée des enfants.
  - Utiliser la batterie dans un endroit sec.

2. Caractéristiques produit

**Batterie Externe Antichoc IP66 avec lampe torche intégrée**

**Norme IP66 : Ne craint pas les fortes projections d'eau, la poussière et les chocs**

**Capacité :** 10 000 mAh

**Dimensions :** 140 x 75 x 27mm  
**Poids :** 224G

**Ports USB :** 2 x 2.1A  
**Port Micro-USB :** 2A

**Type de batterie :** Lythium-Polymère

**Temps de charge :**  
- 8 heures avec un chargeur secteur 5V/2A

**Indicateur de charge :** Digital

3. Diagramme produit



4. Comment recharger sa Rugged

Branchez la Rugged sur un chargeur secteur délivrant 5V/2A en utilisant le câble Micro-USB fourni avec la batterie.

La charge via le port USB d'un ordinateur peut être beaucoup plus longue qu'en utilisant un chargeur secteur.

**5. Comment recharger ses appareils**

Branchez un câble adapté à votre appareil sur le port USB de la Rugged puis allumez la.

**6. Comment allumer la lampe torche**

Appuyez sur le bouton correspondant pendant 2 secondes pour allumer la lampe torche.

@ contact@x-moove.com  
x\_moove  
X-Moove  
www.xmoove.fr

Front : French



1. Precautions

- Please read the following manual before use in order to take full advantage of your Rugged.
- Do not puncture, discard or bend the product.
  - Do not throw the battery into the fire.
  - Do not expose the battery to excessive heat.
  - Do not short-circuit the battery with lead, or other metal products.
  - Do not transport or store the battery with metal objects.
  - Avoid static electricity, strong fields, magnetic and radiation.
  - Do not disassemble the battery or change its structure.
  - Stop using the battery in case of unusual smell or product distortions, or other anomalies.
  - Keep out of reach of children.
  - Use the battery in a dry place.

2. Product characteristics

**IP66 Shockproof Power Bank with integrated flashlight**

**IP66 standard: Resist to strong water splashes, dust and shocks**

**Capacity :** 10 000 mAh

**Dimensions :** 140 x 75 x 27mm  
**Waighte:** 224G

**USB Ports :** 2 x 2.1A  
**Micro USB Ports :** 2A

**Battery cell :** Lythium-Polymer

**Charging time :**  
- 8 hours with a 5V/2A mains charger

**Charge indicator :** Digital

3. Product diagram



4. How to charge your Rugged

Connect the Rugged to a wall plug delivering 5V/2A using the Micro-USB cable supplied with the battery.

Charging via the USB port of a computer can be much longer than using a wall plug.

**5. How to recharge your devices**

Connect a suitable cable for your device to the USB port of the Rugged, and then turn the power on.

**6. How to switch on the flashlight**

Press the flashlight button during 2 seconds to switch on the torch.

@ contact@x-moove.com  
x\_moove  
X-Moove  
www.xmoove.fr

Back : English