

 Pad de Charge Sans-fil POWERGO Pad 	Précautions 1. Merci de lire le manuel d'utilisation avant usage afin de tirer pleinement partie de votre Powergo Pad. 2. Ne pas démonter le pad de charge. Celui-ci n'est pas prévu pour cela. 3. Ne pas utiliser ou stocker votre Pad dans des environnements très chauds ou très humides. 4. Ne pas secouer, percer, découper,cogner ou laisser tomber le Pad. Ne pas mettre au feu ou à l'eau. 5. Ne pas laisser à la portée des enfants. 6. En cas de défaut du produit, anomalies ou autre, arreter immédiatement d'utiliser le produit et contacter le fabricant à l'adresse contact@x-moove.com 7. Afin de tirer pleinement partie du produit, n'utiliser que les accessoires fournis avec ou par le fabricant de votre smartphone, ou par X-Moove.	1. Diagramme produit  2. Caractéristiques produit Pad de charge sans-fil Qi avec signature lumineuse Dimensions : 99 x 99 x 10mm Poids : 95G Charge sans-fil Qi : 10W Android® / 7.5W iPhone® Port USB-C®: 5V-2A / 9V/2A	3. Statuts de la signature lumineuses Blanc fixe : Pad alimenté, en attente d'un appareil Réspiration blanche : Smartphone en charge Rouge clignotant : Smartphone mal positionné Vert : Smartphone chargé 4. Branchement du Pad Pour brancher le Pad, il suffit de brancher le câble USB-C fourni au Pad et à un chargeur secteur. Pour une charge optimale de votre Smartphone, il est conseillé d'utiliser un chargeur secteur délivrant au moins 2A. 5. Chargement de votre Smartphone Pour charger votre Smartphone, il suffit de brancher le Pad comme indiqué précédemment, puis simplement poser votre Smartphone au centre de celui-ci. Si votre Smartphone est compatible avec la charge sans-fil, celle-ci se déclenchera automatiquement et la lumière blanche sous le Pad effectuera une respiration lente et relaxante. Une fois votre Smartphone chargé, la signature lumineuse passera au vert.	Si une fois que vous posez votre Smartphone sur le Pad, la signature lumineuse passe au rouge clignotant, cela signifie soit : - Votre Smartphone est mal positionné, dans ce cas, retirez votre smartphone du Pad et attendez que la signature lumineuse repasse au blanc puis repositionnez votre Smartphone bien au centre du Pad. - Le Pad à détecté un corps étranger métallique. Vérifiez qu'aucun objet n'est posé ou chevauche le Pad (par exemple des clefs, un coupe angle etc...). @ contact@x-moove.com 📷 x_moove 📘 X-Moove 🌐 www.xmoove.fr
---	---	--	--	---

Front : French

 Wireless Charging Pad POWERGO Pad 	Precautions 1. Please read the user manual before use in order to take full advantage of your Powergo Pad 2. Do not disassemble the charging pad. 3. Do not use or store your Pad in very hot or very humid environments. 4. Do not shake, pierce, cut, bump or do not expose to fire or water. 5. Keep out of the reach of children. 6. In case of product defect or anomalies, stop immediately to use the product and contact the manufacturer at contact@x-moove.com 7. In order to take full advantage of the product, only use accessories supplied with or by the manufacturer of your smartphone, or by X-Moove.	1. Product Diagram  2. Product characteristics Qi Wireless Charging Pad with Light Signature Dimensions : 99 x 99 x 10mm Weight: 95G Qi Wireless charge : 10W Android® / 7.5W iPhone® USB-C Port®: 5V-2A / 9V/2A	3. Light Status White : Pad waiting for a device White breathing : Smartphone charging Red flashing : Badly positioned Smartphone Green : Fully charged Smartphone 4. How to plug the Pad To connect the Pad, simply plug in the USB-C cable supplied to the Pad and a wall charger. For optimal charging, it is recommended to use a 2A wall charger. 5. How to charge your Smartphone To charge your smartphone, simply connect the Pad as described above, then put your smartphone on the center of the wireless charging area. If your smartphone is Qi enabled, the charge will be triggered automatically. The light signature will then go to white breathing. Once your smartphone is fully charged, the light will turn green.	If once you put your smartphone on the Pad, the light signature turns red flashing , it means : - That your smartphone is badly positioned. In this case, remove your smartphone from the Pad and wait until the light goes back to white. Then reposition your smartphone right in the center of the Pad. - That the pad detected a foreign metallic object. Check that no objects are placed on the floor or straddles the Pad. @ contact@x-moove.com 📷 x_moove 📘 X-Moove 🌐 www.xmoove.fr
--	--	--	---	---

Back : English